



PUMA

A DIVISION OF VERSATILE INFORMATION PRODUCTS, INC.

DIGITAL RECORDERS AND SOFTWARE
FOR LAW ENFORCEMENT

PUMA-5 Quick Startup Guide

Turn on the PUMA-5

- 1 Slide the ON/OFF switch to the ON position.
- 2 Pull the battery tape protection tab and discard. You will be prompted to set the date and time.



Set the Date and Time

- 1 Press (+ / -) to change the value for the year, month or day.
- 2 Press Next to advance to the next entry.
- 3 After setting the day, press Next to advance the settings to the time.
- 4 Press (+ / -) to select a 12-hour or 24-hour clock and to change the value of the hour and minute.
- 5 Press OK to confirm the date and time.

Charge the Battery

- 1 Plug the USB connector of the included USB cable into a USB port on your computer. You may also use an option AC power adapter or the optional Download/Charging cradle.
- 2 Insert the micro USB plug into the USB port on the bottom of the recorder. Ensure proper alignment and do not force the cable. Your PUMA-5 will begin to charge.
- 3 Please allow a minimum charge of 3 hours for initial charging and before first use.
 - The computer must be turned on when charging the battery.
 - The device may become warm when the battery is being charged.
 - The maximum battery capacity will only be reached after several charging/discharging cycles.

Power Save Setting

The PUMA-5 will enter Power Save Mode automatically if no keys or movement occurs within the pre-set time period. Lifting or moving the recorder will awaken the unit from Power Save Mode. This function does not apply while recording.

Recording in Contact Mode

- 1 Press the front-facing REC (Record) button. Visual and Audible indicators will beep/illuminate.
- 2 Press the front-facing STOP button.
 - Recordings made in Contact Mode are Non-Editable.
 - All side mounted buttons are deactivated while in Contact Mode.

Playback

- 1 Press (+ / -) to navigate to the desired audio file.
- 2 Press the front-facing PLAY button.

A complete PUMA-5 User Guide is available for download at www.pumarecorders.com

You may also request a copy by emailing vip@versatileinformation.com

For Technical Assistance please contact our technical help desk at: 1-800-794-4044

3630 Park Sierra Drive • Riverside, California 92505
(951) 352-8998 • (800) 794-4044 • Fax (951) 352-4593 • www.pumarecorders.com